

Contents of this manual without the permission of the company shall not be free to change and replication, we reserve the right to change the product, if user needs the product further information can contact directly with the supplier.

### 3.6 Product features

This product has the function of paper saving. Before printing, the paper return to the head of the document and then print to avoid wasting too much paper in the head and tail of the paper roll. The printer can print 80mm/58mm width paper roll, equipped with paper width adjuster.

## 4. Communication connection

### 4.1 Wireless connection (Bluetooth)

This series of printers is equipped with a stable wireless connection mode, (SPP / BLE). Bluetooth SPP can support communication printing with mobile terminals installing Android operating system, and Bluetooth BLE can support communication printing with mobile terminals installing iOS operating system.

Bluetooth connection method: After the printer is turned on, search the printer with Android and other Bluetooth communication devices, select the corresponding printer, enter the password (factory default: 0000) for connection, and it can be used normally after successful connection.

Description: The interface is optional, please refer to the actual product purchased

### 4.2 Wired connection (USB or Ethernet interface)

Use the data cables packed with the printer to connect the printer to the PC, and then install the printer driver. The printer driver can be gotten from the attached CD or requested from suppliers or our customer service personnel.

Description: The interface is optional, please refer to the actual product purchased.

## 5. Accessories

Printer	1 pc
USB cable	1 pc
Power adapter	1 pc
User's manual	1 pc
Paper roll	1 pc
Paper width adjuster	1 pc

Description: The specific product accessories may differ from this list. Please take the actual product purchased as. If you have any questions, please consult your supplier timely.

## Appendix:

### Function description of the signal indicator

Bluetooth version: This printer has 2 indicators to remind the user of the status of the printer. Details are as follows:

Operate	Printer status	Blue indicator	Red indicator
Power on	ON	Flash	OFF
Power off	OFF	OFF	OFF
/	Error	OFF	ON
Connect to Bluetooth	Bluetooth connected	ON	OFF
	Bluetooth disconnected	Flash	OFF

Without Bluetooth version: The printer has 2 indicators to indicate the status of the printer. Details are as follows:

Operate	Printer status	Green indicator	Red indicator
Power on	ON	ON	OFF
Power off	OFF	OFF	OFF
/	Error	OFF	ON
/	Out of paper or the paper bin cover opened	OFF	ON
Long Press the FEED button	Feed and cut paper	ON	OFF

# Thermal Receipt Printer User's Manual



## Attentions:


- The printer shall be placed on a flat and stable platform to avoid damage caused by accidental fall.
- The high environment temperature (>45°C) or the low temperature (<5°C) will reduce the print quality.
- The high humidity (>85%RH) or the low humidity (<20%RH) will reduce the print quality.
- Don't open the cover of paper bin in printing process.
- Using low quality or storage too long time print paper will reduce the print quality, even damage the printer.
- If there is dirt at the print head, need to use a soft cotton or cotton swab to dip alcohol and wipe it clean to prevent the print head from being worn.
- Don't touch the print head and retainer directly in order to avoid damaging the print head because of static electricity. Don't scratch or touch the print head with a hardened object to avoid damaging the print head.
- Please try to use up the battery before charging, which can effectively protect the battery life.
- In the course of any accident, please disconnect the printer power supply, and remove the printer battery immediately.
- If user disassemble the printer, the company has the right to refuse warranty on the product.

▲The printer uses a thermistor to detect the temperature of the print head. If the print head overheat, the circuit will cut off the print head and stop printing. The print head is protected by overheating at 80°C.

### Storage Precautions:

- If the printer is not used for a longer time, disconnect the power to the printer power adapter.
- Ordinary thermal printing paper storage time is short. If you want to print documents that need preservation for a long time, please choose long-term thermal printing paper.
- Heat-sensitive printing paper should not be stored in a place with high temperature, high humidity, or direct sunlight. If it has been unsealed, please put it in a place to avoid light.

## 1. Product introduction



## 2. Functions and features

	Items	Parameter
Print parameters	Print method	Thermal dot line printing
	Resolution	203DPI, 8dots/mm
	Print width	72mm (576dots)
	Print speed	100mm/s
Communication	Wired	Standard USB, Ethernet interface
	Wireless	Bluetooth (optional), SPP (Android), BLE (iOS)
Storage	/	POS/ ESC Compatible instruction Set
	RAM	64KB
	FLASH	FLASH: 4MB, NV bitmap FLASH: 64KB
Characters	Chinese	GB18030
	Characters and figures	ASCII
	User defined	Support
	Language (Code page)	Support simplified & traditional Chinese, English and other 45 kinds of international character sets.
Tables	/	Support dots printing with different densities
	/	Support raster bitmap print
Barcode	1 D	UPC-A, UPC-E, EAN-8, EAN13, CODE39, ITF, CODEBAR, CODE128, CODE93
	2 D	QR Code
Detection	Sensor	Paper out, Cover open detection
Indicators	LED	Power indicator, Bluetooth indicator, error indicator
	Type	Standard thermal receipt paper
Printing Paper	Width	80mm
	Thickness	0.056~0.15mm (thermal label paper)
	External diameter	60mm
	Paper loading	Easy to load paper structure
Physical characteristics	Paper tore	Auto cutter
	Operating environment	Temperature: -10°C ~ 50°C, Humidity: 25% ~ 80%RH
	Storage environment	Temperature: -40°C ~ 70°C, humidity: <93%RH (40°C)
Reliability	Size	125.79mm *112mm *96.17mm (Length* Wide*High)
	Weight	0.5Kg (Printer-only)
	TPH life	50Km
Software	Motor life	360,000 hours
	Drivers	Windows (WIN 10/WIN 8/WIN 7/Vista /XP /2000)
	APP	UBUNTU 12.04 32/64 UBUNTU 14.04 32/64 Printer setting tools, etc

## 3. Basic operation

### 3.1 Power on

Connect the power cord and power adapter of the printer, click the feed button, then the printer power on. At this time, the power indicator is on, and the buzzer prompts a beep.

### 3.2 Power off

When the printer on, long press the feed button for 3s can make printer off. At this time, all the indicators off, and the printer off and stops working.

### 3.3 Feed paper (Manual feed)

In the normal working status, click the "Feed" button, the printer will feed paper for 3CM and cut it.

### 3.4 Print self-test page

After the user gets the printer, the printer can be self-test to detect the current settings and working status. When the printer is power off and the print paper is loaded correctly, double click the "Feed" button, the printer will print a self-test page. The self-test page contains information about the current status of the printer, settings and printing examples, such as the Bluetooth PIN, Bluetooth BDA, printing language, program version, font, IP address etc.

### 3.5 Loading paper

In power on and cover open status, load down the suitable size thermal paper roll in correct direction, close the cover, then the printer can print normally. This type can support both 58mm and 80mm width thermal paper.



Loading direction of paper roll